


HIGH SPEED HAIR DRYER

USE MANUAL



USE AND CARE INSTRUCTION MANUAL

Thank you for buying Sppzcur product. Please read these instructions carefully and keep them safe.

WARNING: This appliance is hot. Keep out of reach of children at all times.



Black



Pink



Grey

Model No. : MRD-3238

IMPORTANT SAFEGUARDS

- ▶ This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been supervised/instructed and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be done by children unless they are older than 8 and supervised. Keep the appliance and cable out of reach of children under 8 years.



Do not use this appliance near bathtubs, showers, basins or other vessels containing water.

- ▶ When the appliance is used in a bathroom, unplug it after use since the proximity of water presents a hazard even when the appliance is switched off.
 - ▶ For additional protection, the installation of a residual current device (RCD) having a rated residual operating current not exceeding 30 mA (10mA is ideal) is advisable in the electrical circuit supplying the bathroom.
 - ▶ If the supply cord of this unit becomes damaged, discontinue use immediately and return the appliance to our service for repair or replacement in order to avoid a hazard.
- Always ensure the voltage to be used corresponds to the voltage stated on the unit before plugging the appliance into the mains socket.
 - During use, always ensure the inlet and outlet grilles are not blocked in any way as this will cause the unit to automatically stop. If this should occur, switch off and allow the unit to cool.
 - Keep direct airflow away from eyes or other sensitive areas.
 - Do not allow any part of the appliance touch the face, neck or scalp.
 - Keep the power plug and cord away from heated surfaces.
 - Do not leave the appliance unattended while plugged in.
 - Do not place the appliance on any blankets, towels, cushions or soft furnishings
 - Do not use attachments other than those we supply.
 - Do not set the appliance down while still on.
 - Do not twist or kink the cable, or wrap it round the appliance.
 - Check the cord regularly for any sign damage.

WARNING

1. The hair dryer, filter, and attachments contain magnets, keep away from implanted medical devices such as pace-makers and defibrillators as they may be affected by strong magnetic fields.
2. Do not obstruct the air inlet, this may cause overheating and may present a fire hazard.
3. The air outlet and attachments are hot during usage, do not touch them before they cool down.
4. Do not stretch the wire.
5. Do not unplug the hair dryer by pulling on the wire.
6. Do not allow children to use the hair dryer without the supervision of adults.
7. When using the product for children, it is recommended to start with the lowest speed and lowest temperature setting to avoid scalding.

Parts Identification

1. Airflow outlet
2. Air inlet/Removable filter cage
3. Led display (a. negative ions b. heat c. airflow)
4. On-off switch
5. Cool shot button
6. Heat selector switch
7. Speed selector switch
8. Hang up loop



Product Parameters

Input Voltage: AC100-125V 60Hz;
Power: 1600W
Wind Speed: 3 Levels
Temperature: 4 Levels
Cable length: 2m
Negative Ions: **200** million of ionic

On-off switch

Move up and down this button to shift the hair dryer on and off.
The display shows "OFF" when the hair dryer is in standby mode.

I — Power on

O — Power off

Temperature Setting

4 mode to switch, short press the button

I — Cooler drying

II — 140°F gentle drying

III — 190°F regular warm drying

IV — 250°F fast drying and styling

Speed Setting

3 mode to switch

● — Gentle airflow

●● — Fast airflow

●●● — Strong airflow



Cool shot button

To set your style, press and hold the cold shot button to lock the cold shot on.

Rotating Magnetic Nozzle

The nozzle can be rotated 360° for easy use.

Notice: Install and remove the nozzles in the OFF station. Do not touch the nozzle when the hair dryer is working.

Cleaning and Maintenance

1. Filter should be cleaned and maintained regularly to avoid damage, ensuring that the air inlet is always clean and clear of blockage.

***You can clean the dust and impurities on the filter screen inside the hair dryer with follow 2 modes.**

Automatic cleaning mode

In the standby "off" state, press and hold the Cool shot button switch for 5–10 seconds to start, and it will automatically stop after 10 seconds of cleaning.

Manual cleaning mode

Remove the magnetic filter cap, brush, and wipe away dust buildup on the filter screen with a soft cloth or small brush.



2. Ensure to turn off the hair dryer and unplug it before cleaning the filter cover.

3. The Air inlet filter cover is held in place by a magnet. To remove it, hold the handle firmly and gently pull the filter cover downward.

4. Never wash the filter with water or any other liquid.

5. Clean the outer filter cage and inner filter with a dry cloth or soft brush.

6. After cleaning, mount the filter cage back to the filter, until a soft click noise is heard.

ADDITIONAL FEATURES

Powerful, Fast Drying

The digital motor spins up to 110,000 rpm, propelling the airflow up to 50m/s fast drying.

*50m/s is the speed of hot airflow near the air outlet.

Hair-caring Ionic Technology

The ionic generator produces hundreds million of ionic to neutralize static electricity for smooth and glossy hair.

Noise-reducing Technology

The digital motor is acoustically tuned to reduce noise and be less intrusive in home/salon environments.

Intelligent Heat-control System

The heat-control system measures airflow temperature over 60 times per second to protect your hair from extreme heat damage.

12 Drying Modes

4 Heat Settings and 3 Speed Settings let you find the perfect drying combination for different hair styles and types.

360° Rotating Magnetic Nozzle

Troubleshooting

Exception code	Reason	Abnormal phenomenon	Solution
E06	Air outlet blocked	Motor stops, no wind	1. Ensure that the air outlet is not blocked; 2. If the problem cannot be resolved, contact our after-sales service for warranty.
E09	Motor obstructed, protection activated	Motor stops, no wind	1. Remove any blocks from the inlet grille; 2. Hold Cool Button for 10 seconds to active auto-clean; 3. If the problem cannot be resolved, contact our after-sales service for warranty.
E10	Air inlet continuously blocked, overheating protection activated	Motor stops, no wind	1. Unplug the power, check the air inlet, remove any blocks from the inlet grille; 2. Let the hair dryer cool down for 5 minutes, then plug in and power on; 3. If the problem cannot be resolved, contact our after-sales service for warranty.
E11	NTC temperature detection abnormal	Only cold air, no hot air	1. Unplug and plug the power plug; 2. If the problem cannot be resolved, contact our after-sales service for warranty.
E12	Air inlet briefly blocked, overheating protection activated	Motor stops, no wind	1. Unplug and plug the power plug; 2. Check the air inlet, remove any blocks from the inlet grille; 3. If the problem cannot be resolved, contact our after-sales service for warranty.

Contact Us

Thankyou for choosing sppzcur product. If you have any problems or questions, please contact us at: sppzcur@outlook.com, We will respond as soon as possible.

Warranty Service

Your Sppzcur product is protected by a one-year warranty, effective from the purchase date. Throughout the warranty period, you are entitled to complimentary return, exchange services, subject to presenting a valid purchase invoice. please contact us at: sppzcur@outlook.com.

Limitations of Free Service

The following scenarios are excluded from our complimentary service:

- A. Damages from misuse, deviation from instructions, or negligence.
- B. Repairs or modifications by unauthorized agents or non-Faszin entities.
- C. Damage from using inappropriate power sources or voltages.
- D. Intentional damages.
- E. Damages due to unavoidable external factors.
- F. Normal wear and tear that does not impede the product's functionality.

Final Interpretation Rights: Faszin holds the definitive rights to interpret the terms of this warranty card.



Made in China